R-200/11-R Ratchet Assembly

NOTE: Order parts by Catalog Number only. DO NOT order by Reference Number.

Ref. <u>No.</u>	Catalog <u>No.</u>	Description	
—	37777	Ratchet & Handle Assembly	
1	38585	Handle	
2	39177	Ratchet Assembly	
3	39197	Knob	
4	39182	Ratchet Housing	
5	39172	Spring - Housing	
6	39187	Ratchet Ring	
7	38830	Spring - Ratchet Ring	
8	39192	Pawl	
9	39202	Pawl Spring	



Die Head Assembly

			11-R
Ref. <u>No.</u>	Description		Catalog <u>No.</u>
1	Die Head w/Cover	1/8″	38785
	Plate & Screws	1/4″	38790
		3/8″	38795
		1/2"	38800
		3/4″	38805
	1	" NPT/NPSM	38810
	1	" BSPT/BSPP	74995
	1	/₄″ NPT/NPSM	38815
	11	/4" BSPT/BSPP	41467
		1 ¹ / ₂ "	14603
		2	14608
		16mm ISO	41477
		20mm ISO	41482
		25mm ISO	41487
		32mm ISO	41482
		40mm ISO	41497
2	Cover Plate Screw (4)	¹ / ₈ "- ¹ / ₄ "	38720
		³ /8" -1 ¹ /4"	38750
		1 ¹ / ₂ "-2"	38940
		6mm - 40mm	38750
3	Cover Plate	1/8″	38715
		1/4″	38735
		3/8″	38745
		1/2"	38760
		3/4"	38770
		1″	38780
		1 ¹ / ₄ "	38880
		1 ¹ / ₂ ″	38935
		2	38950





To properly insert new chasers in RIDGID Drop Head Threaders, read the following instructions carefully.

- 1. Place the Die Head in the position shown at left above.
- 2. Remove Screws (4), Cover (2), and old Chasers.
- 3. Insert new Chasers, throats down as shown, into Die Head slots. Numbers on Chasers must agree with those next to Die Head slots.
- 4. Replace Cover (2), and Screws (4). Tighten the Screws lightly.
- Slide Die Head on already threaded nipple or pipe, until Chasers begin to thread. This forces Chasers outward against Lugs on Cover Plate. Tighten the 4 Screws securely. The Chasers are set for accurate threading by bringing B of Chasers against A of the Cover. This is the Key to inserting the Chasers properly.